

# Is my water source good for hydroponics?

Before starting your hydroponic project it is important to know whether your local water source can actually be used to water plants. Not all water sources are compatible with plants and some require special adaptations to the nutrient solution in order to become viable. In this post I will talk about the things that can make a water source unsuitable for hydroponics and the sort of modifications that would be required to make these water sources work with plants. The main points in the post are summarized in the diagram below.




Diagram to figure out if your water can or cannot be used in hydroponics

Tap and well water sources can contain different substances characteristic of the natural environment where the water originated. Water that goes through rocky formations containing a lot of limestone will contain high amounts of

calcium and carbonates, while water that goes through dolomitic rock will contain significant amounts of magnesium as well. Water that contains high amounts of Ca or Mg is not necessarily problematic and can be dealt with by adapting the nutrient solution to account for these ions, you can read more about hard water and its use in hydroponics by reading my [previous post](#) on the subject. These water sources usually need a significant amount of acid to reach the 5.5-6.5 range, so accounting for the nutrient contribution of the acid in the nutrient formulation is also fundamental.

The most problematic water sources will contain high amounts of either sodium or chlorides, two ions that we cannot deal with easily in hydroponics and that can be specially bad for plants. You can read more about sodium in hydroponics [here](#), and chlorides and hydroponics [here](#). Sodium concentrations below 200 ppm can be manageable, but any higher concentrations will invariably lead to issues in hydroponics. Chlorides are even more harmful with the threshold for problems at just 50 ppm. Iron can be similarly problematic as sources that contain high amounts of Fe can be incompatible with plants and the Fe can be difficult to remove. This is why the first step in analyzing a water source should always be an analysis including Na, Cl and Fe. If the values are too high then this water source will require reverse osmosis to be usable.

If Na, Cl and Fe are within limits then we can ask the question of whether this water source is approved for human consumption. If it is then we know that the amounts of heavy metals within it should be low, as well as the amount of other ions, such as nitrate and ammonium. If the water has not been approved by a utility company for human consumption then we need to do heavy metal and nitrate/ammonium analysis to figure out if this is actually safe to use. In some cases well water sources can be perfectly fine to grow plants but the products might be contaminated with heavy metals that make them unsuitable for human consumption.



If a water source is within limits for all of the above then we should take into consideration whether we need custom formulations or whether we can get away with using commercially available hydroponic products "as is". For sources that have relatively low amounts of Fe, Ca and Mg this is usually a possibility but for sources that have quantities of Fe above 2.5 ppm, Ca above 10 ppm or Mg above 5 ppm, it is advisable to go with a custom formulation that can account for the amount of minerals already present within the water. This can still mean using commercially prepared fertilizers only that the mixing ratios and schedules need to be adapted to manage what is already present in the water, so significant deviations from the manufacturer suggestions are to be expected.

Another important point is that none of the above accounts for potential biological activity within the water, which can be a big source of problems in plant culture. *For this reason always make sure to run the water through carbon filtration and have in-line UV filters to ensure that no bacteria, viruses or fungal spores get to your plants through your water source.*


---

# Do you really need to be using R0 water?

One of the most common practices in hydroponics is to use reverse osmosis (R0) water in order to create your hydroponic nutrient solutions. This water is made by running another water source – most commonly tap water – through a reverse osmosis system that removes a very large portion of the ions within the initial water source. The R0 process is very energy intensive and also uses a large volume of water, only around one third of the water input ends up as R0 water while the rest ends up as a more highly concentrated solution. Today we are going to discuss whether using R0 makes the most sense, when it doesn't and how you can make sure that using tap water does not cause you any important issues.

—

CONCENTRATION OF HARDNESS AS CALCIUM CARBONATE,  
IN MILLIGRAMS PER LITER



Mean hardness as calcium carbonate at NASQAN water-monitoring sites during 1975 water year.

Colors represent site data representing streamflow from the hydrologic-unit rea.

(Map edited by USEPA, 2005)

—

The idea behind using R0 water is to have the best “base” for

the construction of a nutrient solution. If your water starts up with some substances within it then the amount of control you have over composition is limited and therefore your results might suffer because of that. If for example your nutrients add 150 ppm of Ca but your water already contains around 40-60 ppm then adding so much Ca might place you within a suboptimal spot. If your water contains a lot of carbonates, sodium, fluorides or other substances they can also cause significant problems within your hydroponic crop. Using RO water brings a "clean slate" that ensures that what you add is what you get.

So what is wrong with RO water? There are two main issues with using RO water. The first is that it's a very energy intensive process – therefore a costly process – and the second is that the waste products of the RO process can create environmental problems. Additionally tap water already contains many nutrients necessary for plant life – mainly Mg and Ca – so why would you remove these elements only to later add them again later on? Surely you would rather save the energy from the RO process and use the nutrients within your water as part of your nutrient solution.

The above map shows you the mean hardness of water (as ppm of calcium carbonate) across the United States. The people with the highest Ca concentrations have around 100ppm of Ca while those who have the least have around 0 to 24ppm. This means that for the people with the highest Ca, the Ca from tap water could contribute more than 50% of the Ca needed by a flowering crop while for the other states the contribution would be rather small. If your water is high in Ca then chances are it is also high in Mg so performing a water analysis will be necessary. From my experience with customers Mg is usually around one fourth to one third the concentration of Ca in solution, but the proportion can change significantly depending on the zip code. The table below shows the Ca/Mg content of water sources at different overall hardness levels

in Germany.

—

total hardness ppm as CaCO <sub>3</sub>	calcium mg/l	magnesium mg/l	calcium hardness mEq/l	magnesium hardness mEq/l
25	7	1.8	0.4	0.2
50	14	3.6	0.7	0.3
75	21	5.5	1.1	0.5
100	28	7.3	1.4	0.6
150	42	10.9	2.1	0.9
200	56	14.6	2.8	1.2
300	84	21.9	4.2	1.8
400	112	29.2	5.6	2.4
500	140	36.5	7.0	3.0
600	168	43.7	8.4	3.6

—

Mineral content in water also changes substantially as a function of temperature since rocks that contribute Ca/Mg carbonates will be more soluble during the warmer months of the year. It is therefore ideal to get two analysis, one during February – usually the coldest month – and another during August, the hottest month, to get a good idea of the range of Ca/Mg concentrations that you will be getting in your tap water. This will allow you figure out how to adjust your nutrients as a function of the average temperature where you live.

Carbonates are also something you should worry about, if you have a high water hardness you might have more than 150ppm of carbonate within your nutrient solution. This is not ideal since carbonate ions can cause issues in your crop. To deal with this you can simply work at a slightly more acidic pH (say 5.6-5.8) this will limit the amount of hydrogen carbonate ions that can be present within the water as it will shift the equilibrium significantly more towards the evolution of carbon dioxide (since carbonic acid in solution is in constant equilibrium with atmospheric carbon dioxide).

There are however some circumstances where using RO water is unavoidable. If you water contains more sodium than your crop

can deal with ([read here](#) for more info), more than 50 ppm of chlorides or if there are more than 10 ppm of fluoride then you will need to use R0 water because those elements in those quantities are not going to be good for your plants. If these elements are absent or in low enough quantities then there is no reason why you would want to use R0 instead of tap as using R0 would be an unnecessary energetic and environmental expense given that you can just compensate for the ions already within your water through adjustments in your nutrient solution.